REMOTE CONTROLS COMPATIBILITY CHART

MANUFACTURER	CAMERA MODEL	REMOTE CONTROLS: MVR901 ECPL — Stand-by, Rec , Zoom	MVR901 ECLA — Stand-by, Rec , Zoom Focus	MVR901 EPLA — Stand-by, Rec , Zoom Focus , Iris (F) , Rec review	MVR901 ECEX — Rec , Zoom , Fast Zoom Rec Review	MVR901 EPEX — Rec , Zoom , Fast Zoom Rec Review	MVR911 ECCN — Rec, Shutter release, Focus, LV on/off, LV zoom, Focus memory	MVR911 EJCN — Rec, Shutter release, Focus, LV on/off, LV zoom, Focus memory, ISO, Aperture, Shutter speed, Colour temp, Exposure comp	S22AV — Adaptor cable jack 2.5mm to Sony AV	NOTES
SONY										
SONY	PMW-150				●	●				
SONY	PMW 200				●	●				
SONY	PMW-300				●	●				
SONY	PMW-EX280				●	●				
SONY	PMW-EX3				●	●				
SONY	PMW-EX1R				●	●				
SONY	PMW-EX1				●	●				
SONY	PXW-X280				●	●				
SONY	PXW-FS5	● L	●	●						
SONY	PXW-FS5 Mark II	● L	●	●						
SONY	PXW-FS7	● L	●	●						
SONY	PXW-FS7 Mark II	● L	●	●						
SONY	PXW-FX9	● L	●	●						
SONY	PXW-Z90	● L	●	●					●	
SONY	PXW-Z150	● L	●	●						
SONY	PXW-Z190	● L	●	●						
SONY	PXW-Z280	● L	●	●						
SONY	HXR-MC2000	● L	●	●						
SONY	HXR-MC2500	● L	●	●						
SONY	HXR-MC50	● L	●	●					●	
SONY	HXR-MC88	● L	●	●					●	
SONY	HXR-NX30	● L	●	●					●	
SONY	HXR-NX3D1	● L	●	●					●	
SONY	HXR-NX3	● L	●	●						
SONY	HXR-NX5	● L	●	●						
SONY	HXR-NX5R	● L	●	●						(3*)
SONY	HXR-NX70	● L	●	●					●	(3*)
SONY	HXR-NX80	● L	●	●					●	(3*)
SONY	HXR-NX100	● L	●	●						(3*)
SONY	HXR-NX200	● L	●	●						(3*)
SONY	ILME-FX6	● L	●	●						
SONY	NEX-EA50	● L	●	●						(2*)
SONY	NEX-FS100	● L	●	●						(2*)
SONY	NEX-FS700	● L	●	●						(2*)
SONY	NEX-VG20	● L	●	●					●	
SONY	NEX-VG30	● L	●	●					●	
SONY	NEX-VG900	● L	●	●					●	
SONY	HVR-A1	● L	●	●						
SONY	HVR-HD1000	● L	●	●						
SONY	HVR-S270	● L	●	●						
SONY	HVR-V1	● L	●	●						
SONY	HVR Z5	● L	●	●						
SONY	HVR-Z7	● L	●	●						
SONY	HVR-Z1	● L	●	●						
SONY	HDR-AX2000	● L	●	●						
SONY	HDR-FX1	● L	●	●						
SONY	HDR-FX7	● L	●	●						
SONY	HDR-FX1000	● L	●	●						
SONY	DSR-PD175P	● L	●	●						
SONY	DCR-DVDxxx	● L	●	●					●	
SONY	DCR-SRxx	● L	●	●					●	
SONY	DCR-SXxx (except DCR-SX22E)	● L	●	●					●	
SONY	DCR-CXxx	● L	●	●					●	
SONY	DCR-VX2000	● L	●	●						
SONY	HDR-SRxx	● L	●	●					●	
SONY	HDR-TGxx	● L	●	●					●	
SONY	HDR-TD30V	● L	●	●						
SONY	HDR-XRxx	● L	●	●					●	
SONY	HDR-UX10	● L	●	●					●	
Canon										
Canon	EOS C100	● L	●	●						(4*)
Canon	EOS C200/C200B	● L	●	●						(4*)
Canon	EOS C100 Mark II	● L	●	●						(4*)
Canon	EOS C300	● L	●	●						(4*)
Canon	EOS C300 Mark II	● L	●	●						(4*)
Canon	EOS C300 Mark III	● L	●	●						(4*)
Canon	EOS C500	● L	●	●						(4*)
Canon	EOS C500 Mark II	● L	●	●						(4*)
Canon	EOS C70	● L	●	●						(4*)
Canon	EOS C700/C700PL	● L	●	●						(4*)
Canon	EOS C700 GS-PL	● L	●	●						(4*)
Canon	EOS C700 FF-PL	● L	●	●						(4*)
Canon	XF100	● L	●	●						
Canon	XF105	● L	●	●						
Canon	XF200	● L	●	●						
Canon	XF205	● L	●	●						
Canon	XF300	● L	●	●						
Canon	XF305	● L	●	●						
Canon	XF400	● L	●	●						
Canon	XF405	● L	●	●						
Canon	XF605	● L	●	●						
Canon	XF705	● L	●	●						
Canon	XA10	● L	●	●						(5*)
Canon	XA11	● L	●	●						(5*)
Canon	XA15	● L	●	●						
Canon	XA20	● L	●	●						(5*)
Canon	XA25	● L	●	●						(5*)
Canon	XA30	● L	●	●						(5*)
Canon	XA35	● L	●	●						(5*)
Canon	XA40	● L	●	●						(5*)
Canon	XA45	● L	●	●						(5*)
Canon	XA50	● L	●	●						(5*)
Canon	XA55	● L	●	●						(5*)
Canon	XA60	● L	●	●						
Canon	XA65	● L	●	●						
Canon	XA70	● L	●	●						
Canon	XA75	● L	●	●						
Canon	XL H1S	● L	●	●						
Canon	XL H1A	● L	●	●						
Canon	XH A1/A1S	● L	●	●						
Canon	XH G1/G1S	● L	●	●						
Canon	XL H1	● L	●	●						
Canon	XM1 / XM2	● L	●	●						
Canon	GL1 / GL2	● L	●	●						
Canon	HF-G25	● L	●	●						
Canon	HF-G30	● L	●	●						
Canon	HF-G40	● L	●	●						
Canon	EOS 1Dx						●	●		
Canon	EOS 1Dc						●	●		
Canon	EOS 6D						●	●		
Canon	EOS 5D mkIII						●	●		
Canon	EOS 5D mkII						●	●		
Canon	EOS 70D						●	●		
Canon	EOS 60D						●	●		
Canon	EOS 1D mkIV						●	●		
Canon	EOS 7D						●	●		
Canon	EOS 600D						●	●		
Canon	EOS 550D						●	●		
Canon	EOS 500D						●	●		
Panasonic										
Panasonic	AG-3DA1	● P								(6*)
Panasonic	AG-3DP1	● P								(6*)
Panasonic	HDC-Z10000	● P								(6*)
Panasonic	AG-AC30	● P								(6*)
Panasonic	AG-AC130/130A	● P								(6*)
Panasonic	AG-AC160/160A	● P								(6*)
Panasonic	AG-AC90	● P								(6*)
Panasonic	AG-AF100/101/100A	● P								(6*)
Panasonic	AG-CX10	● L	●	●						(7*)
Panasonic	AG-CX350	● L	●	●						(7*)
Panasonic	AG-HMC150/151/150PJ	● P								(6*)
Panasonic	AG-HMC40/41/40PJ	● P								(6*)
Panasonic	AG-HMC80/81/80PJ	● P								(6*)
Panasonic	AG-HPX250/255/250PJ	● P								(6*)
Panasonic	AG-HPX270PJ	● P								(6*)
Panasonic	AG-HVX200/201/200A/201A	● P								(6*)
Panasonic	AG-HPX175	● P								(6*)
Panasonic	AG-DVX100	● P								(6*)
Panasonic	AG-DVX200	● P								(6*)
Panasonic	AG-DVC80	● P								(6*)
Panasonic	AG-DVC30	● P								(6*)
Panasonic	AG-HMR10	● P								(6*)
Panasonic	AG-HCK10/10G	● P								(6*)
Panasonic	AG-UX90	● P								(6*)
Panasonic	AG-UX180	● P								(6*)
Panasonic	AJ-PX230	● P								(6*)
Panasonic	AJ-PX270	● L	●	●						(7*)
Panasonic	AJ-PX270PJ	● P								(6*)
Panasonic	AU-EVA1	● L	●	●						(7*)
Panasonic	HC-X1	● P								(6*)
Panasonic	HC-X1000	● P								(6*)
Panasonic	HC-X1500	● L	●	●						(7*)
Panasonic	HC-X2	● L	●	●						(7*)
Panasonic	HC-X20	● L	●	●						(7*)
Panasonic	HC-X2000	● L	●	●						(7*)
Panasonic	DMC-GH4	● P								(6*)
Panasonic	DC-GH5	● P								(6*)
JVC										
JVC	GY-HC500	● L	●	●						(7*)
JVC	GY-HC550	● L	●	●						(7*)
JVC	GY-HM170	● L	●	●						(7*)
JVC	GY-HM180	● L	●	●						(7*)
JVC	GY-HM200	● L	●	●						(7*)
JVC	GY-HM250	● L	●	●						(7*)
JVC	GY-HM600	● L	●	●						(7*)
JVC	GY-HM620U	● L	●	●						(7*)
JVC	GY-HM650	● L	●	●						(7*)
JVC	GY-LS300	● L	●	●						(7*)
Blackmagic										
Blackmagic	Pocket Cinema Camera		●	●						(8*)
Blackmagic	Cinema Camera EF		●	●						(8*)
Blackmagic	Production Camera 4K		●	●						(8*)
Blackmagic	URSA EF		●	●						(8*)
Blackmagic	URSA Mini EF		●	●						(8*)
Blackmagic	URSA Broadcast G2		●	●						(8*)
Blackmagic	URSA Mini Pro 4.6K G2		●	●						(8*)
Blackmagic	URSA Mini Pro 12K		●	●						(8*)
Blackmagic	Micro Studio Camera 4K		●	●						(3*)
Blackmagic	Studio Camera HD		●	●						(3*)
Blackmagic	Studio Camera 4K		●	●						(3*)

REMOTE CONTROL	ACCESSORIES: MVR901 APCL	S22 AV	S22 SCA	S23 RC
MVR901 ECPL		●	●	●
MVR901 ECLA		●	●	●
MVR901 EPLA	●	●	●	●
MVR901 ECEX				●
MVR901 EPEX	●			●
MVR911 ECCN				
MVR911 EJCN				

● : compatible

● L : compatible, switch MVR901ECPL to LANC mode

● P : compatible, switch MVR901ECPL to Panasonic mode

DISCLAIMER
The information contained in this document is subject of change without notice.
Manfrotto makes no warranty and shall not be liable for any errors on information contained in this document.
All trademarks are property of their respective owners.

(1*) Iris compatibility: behaviour depends on the camcorder model.
(2*) may not be available: Zoom, Autofocus (depending on lens).
(3*) compatibility of features depends on camera model (e.g. Stand-by, Rec may not be available).
(4*) availability of: Zoom, Autofocus; Autoiris, Iris controls depends on specific camera model and mounted lens; please refer to camera user manual for more details.
(5*) not available: Rec review, Autoiris, Iris.
(6*) not available: Stand-by. Switch MVR901ECPL in Panasonic compatibility.
(7*) not available: Stand-by.
(8*) not available: Stand-by; availability of Zoom depends on lens type.

Version: April 2023