



## **Directors Set**

*DJI Mavic Air 2S*

---

# What's Included

## **DIRECTORS SET**

*Filters* (ND8-PL | ND16-PL | ND32-PL | VND 2-5 & 6-9 stop)

*Magnetic Case* | *Microfiber Cloth*

---

## Installation

### **Step 1**

Install the filter before powering-on the drone.

### **Step 2**

Support the gimbal in one hand. Using your other hand, push, and turn the stock UV counterclockwise and remove.

### **Step 3**

Make sure your Air 2S lens is clean and clear of debris before filter installation.

### **Step 4**

Support the gimbal in one hand. Using your other hand, place the filter tabs into their corresponding lens slots. When seated flush to the lens, turn clockwise until filter clicks into place.

---

## Installation (Continued)

### **Step 5** *(ND/PL Filters Only)*

Once installed, make sure the reference line aligns with the triangle on the filter base for horizontal polarization.

### **Step 6** *(VND Filters Only)*

Rotate gold bezel to desired stop value. Verify the stop value aligns with the triangle located on the filter base.

### **Pro Tip**

For most natural looking composition, make sure the reference line aligns with the triangle on the filter base. Too much polarization can make your scene look unrealistic.

---

## More Info

### *Tutorials*

For additional help be sure to visit our YouTube page:

**[youtube.com/polarprofilters](https://www.youtube.com/polarprofilters)**

for tutorials and more.

### *Questions*

Contact us at anytime via our website, or shoot us an email. We're happy to help.

**[polarpro.com](https://polarpro.com) | 949.220.9395**

**[support@polarpro.com](mailto:support@polarpro.com)**