# QUICK START GUIDE
# WR-150
## remote control WIRED

**For use with Datavideo Teleprompter kits**
**TP-600, TP-500, TP-300 and TP-100**

datavideo®
Sharing the Value



## Packing List

1 x **WR-150** Remote Control with jack plug connector
1 x **USB A to Micro B USB cable** for charging

## Overview

This **WR-150** remote control is designed to be used with Datavideo's teleprompter app, **DV Prompter**.

**DV Prompter app is a FREE download** from the Apple app store for iOS devices and also from Google Play for Android devices. Search for DV Prompter.

**A separate manual is provided for the DV Prompter app**, for further details please visit our website shown on the rear cover.

**NOTE:** The remote should NOT be opened for any reason as this will invalidate the warranty.

## Charge the remote control before use




There is a rechargeable battery inside the remote. Use the separate Micro B USB to USB A cable provided to charge the remote by connection to PC or Mac computer. Connect this cable to the USB port (1).

**Charge the remote for 2 hours via USB connection to computer.**

The RED charging LED will disappear when the battery is fully charged.

Alternatively, a 5V smart phone USB wall charger can be used instead.

**NOTE:** The remote should NOT be opened for any reason as this will invalidate the warranty.

## PROBLEMS? FACTORY RESET

If the remote should stop working or is not controlling the app as expected **it may simply be a low battery condition**. Please follow this checklist before contacting your supplier for help.

1. Is the GREEN activity LED on the remote being shown when a button is pressed? If no, **please try recharging the unit** with the USB cable provided or a compatible 5V USB wall charger. See the charge remote before use section.
2. When the RED LED is shown during charging **this will automatically wipe the remotes memory and cause a factory reset**.
3. If the remote is still not controlling the DV Prompter app on the tablet device **check the REMOTE menu option** in the **DV Prompter** app. It should be **set to Wired – WR-150**.
4. If the remote has been charged and the app is also set to Wired – WR-150 then double check the control cable to jack plug for damage. If damaged please contact your local supplier for help.
5. Still not working? Is the stereo jack plug end of this control cable connected to the headset socket of the tablet being used?
6. If it still isn't working at this point then we need to check if your tablet or smart phone can accept microphone input via its headphone socket. Please check your tablet / smart phone's user manual.
7. You may call your local supplier or Datavideo office for assistance.

## Service & Support

It is our goal to make your products ownership a satisfying experience. Our support staff can be contacted during normal office hours . They can assist you in setting up and understanding this product. Please refer to our web site www.datavideo.com for answers to common questions, support requests or contact your local Datavideo office below.

Datavideo Global Website: www.datavideo.com


**Datavideo Corporation**
USA
Tel: +1-562-696 2324
Fax:+1-562-698 6930
techsupport@datavideo.us

**Datavideo Technologies**
Europe
Tel: +31-30-261-96-56
Fax:+31-30-261-96-57
info@datavideo.nl

**Datavideo UK Limited**
UK
Tel: +44-1457 851 000
Fax:+44-1457 850 964
sales@datavideo.co.uk

**Datavideo Technologies**
Taiwan, R.O.C.
Tel: +886-2-8227-2888
Fax: +886-2-8227-2777
service@datavideo.com.tw

**Datavideo Technologies**
Shanghai, China
Tel: +86 21-5603 6599
Fax: +86 21-5603 6770
service@datavideo.cn

**Datavideo Technologies**
Singapore
Tel: +65-6749 6866
Fax: +65-6749 3266
sales@datavideo.sg

**Datavideo Hong Kong Ltd**
Hong Kong
Tel: +852-2833-1981
Fax: +852-2833-9916
info@datavideo.com.hk

**Datavideo France s.a.r.l**
France
Tel: +33-1-60370246
info@datavideo.fr

**Datavideo Technologies**
India
Tel: +91-0120-2427337
Fax:+91-0120-2427338
sales@datavideo.in


Please refer to our website for the latest PDF version of this manual

http://www.datavideo.info/Teleprompters/WR-150


All the trademarks are the properties of their respective owners.
Datavideo Technologies Co., Ltd. All rights reserved 2014.



**09 May 2014 - P/N: WR-150 E1**


## Connections and Controls




1. Micro B USB socket for charging and control cables.
2. Charging & activity LEDs.
3. Control cable to stereo jack plug.

**Speed up text scroll**

**Slow down text scroll**

**Previous Break Marker**

**Next Break Marker**

**Play text / Pause text**

## First use – Wired Remote

When first removed from the retail package the remote may need to be charged, See **charge remote before use** section.

The jack plug on the remote needs to be connected to the headphone socket on the tablet or smart phone that is running the DV Prompter app.



**NOTE:** When using this remote the **DV Prompter app** should be set to **Wired – WR150** under the *menu option* ***Remote.***

## Frequently Asked Questions

**Q1: Can the remote be used with Apple tablet and smart phone devices?**
A1 : Yes.

**Q2: Can I charge the device with my smart phone wall charger?**
A2: Yes, a 5V, Micro B USB, wall charger will charge this remote.

**Q3: How long does it take to charge the remote?**
A3: For a full charge wait for the RED charging LED to go off.
Maximum charge time required, two hours.

**Q4: Can the WR-150 remote be used with Android tablet and smart phone devices?**
A4: It will work with some Android tablets and most smart phones. Check first if your device supports microphone input on its headset jack socket. If it does not then you may still be able to use the Bluetooth version of this remote, the WR-450.

**Q5: Can the remote be used to control several devices at once?**
A5: No. The remote is designed for use with one teleprompting device.

**Q6: How do I switch the unit off?**
A6: The device does not use power when idle so does not need to be switched on or off.

**Q7: Where can I find instructions for the free DV Prompter App?**
A7: A separate PDF manual is available for download from our website.

**Q8: Are Windows tablets and smart phones supported?**
A8: No, currently there is no windows based app for this remote.

**Q9: Will this remote work with other apps?**
A9: No, the remote is designed for use with the DV Prompter app only.